

Aprehend Spray Gun Trigger-Lock Retrofit Assembly Instructions

Aprehend[®]

Biological Bed Bug Control

Before starting, ensure that the reservoir is empty.



1. Remove the trigger mechanism using the supplied wrench.



2. Install new trigger-lock mechanism—wrench tighten 1/2-turn past hand-tight.
3. Run system with Trigger-Lock in “OFF” (unlocked) position and empty reservoir to **confirm leak-free connection**—this will allow proper compressor auto-stop operation during use.

If the compressor continues to run when trigger is not depressed, wrench tighten further.



ON (Locked)
Clockwise



OFF (Unlocked)
Counter-clockwise



Press and twist to toggle between the Trigger-Lock “ON” and “OFF” positions.

**Be sure to
check out
The
Aprehend
Channel
on YouTube**

