

Foamer Simpson™ 5.0

5 Liter (1.3 Gallon) Foamer - Instruction Sheet

1. Remove all components from packaging. Attach the extension wand to the trigger handle.
2. Securely hold the tank and unscrew the pump assembly (blue handle) from the tank.
3. For the best quality foam, do not fill the foamer to more than 1 gallon. Since air is required to make the foam as well as for pressurizing the foamer, the extra head space is necessary.
4. Fill the foamer to the desired level with water, then add the InVade Bio Foam (1 oz per quart or 4 oz per gallon), or OutLAST Pro Foaming Agent followed by the chemical you are foaming, per label directions.
5. Swirl the foamer to mix, but do NOT shake.
6. Pressurize the tank by pumping up the unit to the desired pressure or until the pressure release valve begins to leak air.
7. Once the desired pressure has been achieved, push the pump handle down and twist it clockwise to lock it in place. You are now ready to start foaming.
8. While InVade Bio Foam and OutLAST Pro are not corrosive, it is a good idea to clean the foamer regularly with fresh water to extend its life.
9. If using other products in the foamer, make sure they are compatible with plastic parts.
10. Always depressurize the foamer using the green relief valve on the side (until the red part of the stem is visible) after use and prior to removing the pump. Beware of spray.
11. It is important to keep adequate pressure in the tank to maintain foam consistency.
12. It may be necessary to clean, and periodically replace the white foam insert in the nozzle to maintain foam quality after multiple uses.

Visit <https://www.rockwelllabs.com/invadefoamersimpson.html> for more information.

Foamer Simpson™

Instructions for Use (2016 to 6/2020)

1. Before use, unlock and lift the pump handle and put three drops of vegetable oil directly into the pump opening where the pump handle locks into place. Repeat approximately weekly if using the foamer regularly to prolong the life of the pump. If it becomes difficult to pump, it likely needs oil.
2. For best quality foam, do not fill the foamer to more than 1 gallon. Since air is required to make the foam as well as for pressurizing the foamer, the extra headspace will help.
3. Fill the foamer to the desired level with water, then add the InVade Bio Foam (1 oz per quart or 4 oz per gallon).
4. Swirl the foamer to mix, but do NOT shake. If a large amount of foam develops in the headspace, it can possibly block the air intake, resulting in poor quality foam. This should only happen if the foamer is shaken vigorously, and not from normal use. If this happens,
5. While InVade Bio Foam is not corrosive, it is a good idea to clean the foamer regularly with water to extend its life.
6. If using other products in the foamer, make sure they are compatible with plastic parts.
7. Always depressurize the foamer using the valve on the side after use and prior to removing the pump. Beware of spray.
8. It is important to keep adequate pressure in the tank to maintain foam consistency.
9. To use the extension wand, remove the short nozzle and screw in the extension wand.
extension wand as this improves the quality of the foam.
10. It is necessary to clean, and periodically replace the white foam insert in the nozzle to maintain foam quality after multiple uses.

Visit www.rockwelllabs.com/FoamerSimpson.shtml for more information.

Foamer Simpson™

Original Model Instructions for Use

1. Before use, unlock and lift the pump handle and put three drops of oil from the enclosed bottle directly into the pump opening where the pump handle locks into place. Repeat approximately weekly if using the foamer regularly to prolong the life of the pump. If it becomes difficult to pump, it likely needs oil.
2. For best quality foam, do not fill the foamer to more than 1 gallon. Since air is required to make the foam as well as for pressurizing the foamer, the extra headspace will help.
3. Fill the foamer to the desired level with water, then add the InVade Bio Foam (1 oz per quart or 4 oz per gallon).
4. Swirl the foamer to mix, but do NOT shake. If a large amount of foam develops in the headspace, it can possibly block the air intake, resulting in poor quality foam. This should only happen if the foamer is shaken vigorously, and not from normal use. If this happens, pour out the liquid and rinse out the foam and refill.
5. While InVade Bio Foam is not corrosive, it is a good idea to clean the foamer regularly with water to extend its life.
6. If using other products in the foamer, make sure they are compatible with plastic parts.
7. Always depressurize the foamer using the valve on the side after use and prior to removing the pump. Beware of spray.
8. The foam consistency can be adjusted by turning the needle valve where the hose connects to the tank. Turning it clockwise (tightening) will use less air, for wetter foam. Turning it counter clockwise (loosening) will result in more air for drier foam.
9. To use the extension wand, remove the short nozzle and screw in the extension wand. Make sure that the piece of white filler looking material remains in the nozzle or extension wand as this is critical for foaming.